

Step 5

1) Measure the generator no-load performance. (☞ 6-10)

Is the generator no-load performance OK?

YES	Go to Step 6.
NO	Faulty generator.

Step 6

1) Inspect the regulator/rectifier. (☞ 6-10)

Is the regulator/rectifier OK?

YES	Go to Step 7.
NO	Faulty regulator/rectifier.

Step 7

1) Inspect wiring harness.

Is the wiring harness OK?

YES	Faulty battery.
NO	<ul style="list-style-type: none"> • Short circuit of wiring harness. • Poor contact of couplers.

Battery overcharges

- Faulty regulator/rectifier.
- Faulty battery.
- Poor contact of regulator/rectifier lead wire coupler.

INSPECTION**BATTERY CURRENT LEAKAGE**

- Remove the seat. (☞ 5-4)
- Turn the ignition switch to the OFF position.
- Disconnect the battery \ominus lead wire.
- Measure the current between \ominus battery terminal and the \ominus battery lead wire using the multi-circuit tester. If the reading exceeds the specified value, leakage is evident.

TOOL 09900-25008: Multi-circuit tester set

TESTER Tester knob indication: Current (---, 20 mA)

DATA Battery current (leak): Under 1 mA

CAUTION

- * In case of a large current leak, turn the tester to high range first to avoid tester damage.
- * Do not turn the ignition switch to the "ON" position when measuring current.

NOTE:

When checking to find the excessive current leakage, remove the couplers and connectors, one by one, checking each part.

