


MAGNETO



- 1. Nut (3)
- 2. Lock washer (3)
- 3. Starting pulley
- 4. Starting pulley stud (3)
- 5. Magneto housing
- 6. Centrifugal lever spring
- 7. Centrifugal lever
- 8. Bearing screw
- 9. Magneto ring
- 10. Lock washer (4)
- 11. Allen screw (4)
- 12. Coil retaining screw (4)
- 13. Lock washer (4)
- 14. Lighting coil
- 15. Ignition generator coil
- 16. Capacitor charging coil

- 17. Capacitor (2)
- 18. Washer (2)
- 19. Lock washer (2)
- 20. Allen screw (2)
- 21. Armature plate
- 22. Breaker point set
- 23. Breaker point (unit construction)
- 24. Pivot pin
- 25. Bolt
- 26. Lock washer
- 27. Nut
- 28. Screw
- 29. Lock washer
- 30. Washer
- 31. Washer
- 32. Retaining clip